

skike

Install Mudguards (6" and 8" wheels)

BDA 001

Anbau Schmutzfänger (6 + 8 Zoll)

Instalar guardabarros (6 y 8 pulg.)

Installer les garde-boue (6" ou 8")

v9 FIRE 150 / v9 FIRE 200 / v9 TOUR 150 / v9 TOUR 200 / v9 WALK HYBRID

skike Item IDs : 13026 13028

